

ELECTRIC TARIFF

RULES, REGULATIONS AND CONDITIONS OF SERVICE

15. COMPANY'S INSTALLATION

Installation and Maintenance. Company will install and maintain its line and equipment on its side of Point of Delivery, but shall not install or maintain any equipment or lines on Customer's side of Point of Delivery, excepting meters and meter enclosures.

Service Connection to Customer

Overhead: Employees of the Company shall install an overhead service connection from the Company's lines to a point of attachment on Customer's building; connect to the Customer's service entrance and install the meter, all at the expense of the Company.

Underground: Employees of the Company shall install an underground service connection from the Company's lines to a point of delivery in accordance with the provisions of the Company's standards.

Protection by Customer: Customer or property owner will exercise due care for the protection of Company property.

PUBLIC UTILITY COMMISSION OF TEXAS
APPROVED

JUL 27 '07 DOCKET 32766

CONTROL # _____

